

SERIE 150.200

HP 70/200 - KW 51/147

10/35 cm - 4/14 in




3p. Cat II



3514

Mod.	cm	↔ in	HP min / max	KW min / max	N. ↓ ↓	kg	Lb
R 2510	245	96	70/200	51/147	10	1480	3262
R 2710	270	106	75/200	55/147	10	1510	3329
R 2712	270	106	75/200	55/147	12	1660	3660
R 3012	300	118	80/200	58/147	12	1700	3748
R 3514	350	138	90/200	66/147	14	1920	4233
R 4016	400	157	100/200	73/147	16	2140	4718



1,5 / 2,6 Km/h

0,9 / 1,6 miles/h



Selvatici usa solo cuscinetti =
- attrito/manutenzione +
durata/scorrevolezza

Selvatici use only bearings =
- friction/repairs + durability/smoothness

Selvatici utilise uniquement des roulements =
- frottement/entretien + durée/glisement.

Selvatici usa sólo cojinetes =
- fricción/mantenimiento + duración/
deslizabilidad.

Selvatici verwendet nur Lager mit
- Reibung/ Wartung + Lebensdauer/
Gleitfähigkeit.